



The MAS by JABEPRODE™ is provided by Raw Mellifera Ltd for distribution in the United Kingdom. Any enquiries, please refer to contact details at the end of this document.



How To Build Your Trap with the MAS device:



Fig 1



Fig 2

Once you will have purchased your MAS kit, you will need some boxes. Any type of boxes will do a long as they are stackable. At Raw Mellifera, we are using AUER boxes (references below) but you can also build your own out of any timber, plywood, pallet wood.... or even reuse some old super and brood boxes.

The set consist in 2 boxes and a roof (fig.1) (the roof is not represented on the picture) , The shallow box (400 x 300 x 75 mm) goes underneath the main one. The bottom of the main box (400 x 300 x 220 mm) where the Asian Hornets will be trapped will be cut, fitted with a 2 mm mesh floor (Fig.1) and the box will need 2 MAS (Fig.2).

The distance between the 2 narrow extremities of the MAS shall imperatively be 80 mm minimum. The mesh used in our construction is A4 dimensions. Old mesh from a beehive floor can be used too.

For the main box, the cut to fit the MAS shall be centred on the end panels of the box, with cut dimensions as follow:135 x 197mm.

If your main box has hollow handles, as for some AUER boxes, you will need to use some extra mesh or plain pieces of plastic (from the bottom cut) to close them.



The Shallow box does not need any modification, it will receive the baits placed into containers (take away type containers).

To fix the mesh, we use 2.4 mm rivets. If you do not have any, you can also glue the mesh with silicon, glue gun , polyurethane glue or screw it. The same applies for the MAS apart from the rivets. For extra security you can zip tie the MAS to the box by drilling small hole to fit the zip ties.



Boxes references:

Bottom box: AUER EG 43/75 HG

Main box: AUER EG 43/22 HG

Lid: AUER DE 43

AUER website: <https://www.auer-packaging.com/gb/en/>

Contact and Enquiries:

Raw Mellifera Ltd, 55 Castlehaven Close SN15 3TG Chippenham, United Kingdom

Website: www.rawmellifera.co.uk

Phone: (+44) 07462897203

Email: raw.mellifera@yahoo.com

For any individual order of the MAS, please go on the website to order directly. For any bulk order (50 kits minimum) please do Email us with your requirement. Please allow 30 to 45 days delivery delay due to international shipping. All orders to be paid upfront.